


f.u.n.k.e ATR833 Adapter BLE Bluetooth

sky-map EXPERIMENTAL



Bluetooth Low Energy adapter (BLE) for a f.u.n.k.e ATR833 VHF transceiver (aviation radio). The adapter was developed as an interface for a f.u.n.k.e ATR833 to the navigation software sky-map. It implements the data transfer between the navigation software (SD) and the radio hardware (BLE \leftrightarrow RS-232). The adapter simply connects to the radio.

No additional power supply is required. The adapter is powered through the radio. A self-resetting fuse is integrated in the housing. The power supply is protected against reverse polarity and short-circuit proof.

No further electrical work necessary!

Important: This is a prototype for experimental use only!



1 Radio Configuration

No further configuration is required on the radio.

2 Connector Pin Assignment

This is an excerpt from the f.u.n.k.e installation manual:

| | | | |
|------------|----|----|--------------|
| MIC-R-GND | 14 | 1 | LSP(+) |
| /PTT-L | 15 | 2 | HEAD(+) |
| LSP(-) | 16 | 3 | HEAD(-) |
| /PTT-R | 17 | 4 | EXT-NF |
| MIC-R-STD | 18 | 5 | MIC-R-DYN |
| MIC-L-STD | 19 | 6 | MIC-L-GND |
| AUTO-ON | 20 | 7 | INTERCOM |
| DATA-GND | 21 | 8 | MIC-L-DYN |
| DATA-TX | 22 | 9 | DATA-RX |
| LCD-LIGHT | 23 | 10 | (leave open) |
| SW-12U-OUT | 24 | 11 | +12U-PWR |
| GND | 25 | 12 | +12U-PWR |
| | | 13 | GND |

D-SUB Connector Female
seen from solder side

Figure 1: Old Version (ATR833)

4.7.2 Connector – Pin Allocation

| | | | |
|-------------------|----|----|-------------------|
| MICR GND | 14 | 1 | LSP (+) |
| PTT0 | 15 | 2 | HEAD0 (+) |
| LSP (-) | 16 | 3 | GND (HEAD0) |
| PTT1 | 17 | 4 | EXT NF |
| MICR STD | 18 | 5 | MICR DYN |
| MICL STD | 19 | 6 | MICL GND |
| HEAD1 (+) | 20 | 7 | INTERCOMSWITCH |
| GND (HEAD1) | 21 | 8 | MICL DYN |
| DATA TX | 22 | 9 | DATA RX |
| do not connect | 23 | 10 | do not connect |
| +5VDC (TO REMOTE) | 24 | 11 | BATT (+) (14/28V) |
| BATT (-) | 25 | 12 | BATT (+) (14/28V) |
| | | 13 | BATT (-) |

D-SUB Connector 25 Pin Female
seen from solder side

Figure 2: New Version (ATR833-II)




| Pin | Names | Functionality |
|-----|-----------------|---|
| 1 | LSP(+) | Output external Loudspeaker Positive |
| 2 | HEAD-0 (+) | Output Headset-Speaker Positive |
| 3 | GND (HEAD-0) | Output Headset-Speaker Negative |
| 4 | EXT-NF | Input external Audio-Signal |
| 5 | MIC R DYN | Input Microphone Right Dynamic |
| 6 | MIC L GND | Input Microphone Left Ground |
| 7 | INTERCOM SWITCH | Intercom Activation Switch (connect to ground for Intercom activation) |
| 8 | MIC L DYN | Input Microphone Left Dynamic |
| 9 | DATA-RX | RS232 Receive (for Remote Control) |

| | | |
|----|----------------|--|
| 10 | do not connect | Pin 10 is used by adapters for device identification |
| 11 | +14 / +28V-PWR | Input Power Supply +12V |
| 12 | +14 / +28V-PWR | Input Power Supply +12V |
| 13 | BATT (-) | Ground Side of Power Supply |
| 14 | MIC R GND | Input Microphone Right Ground |
| 15 | PTT-0 | Push-to-Talk 0 (connect to ground for transmitting) |
| 16 | LSP(-) | Output external Loudspeaker Negative (Not identical to ground!) |
| 17 | PTT-1 | Push-to-Talk 1 (connect to ground for transmitting) |
| 18 | MIC R STD | Input Microphone Right (Headset 1) |
| 19 | MIC L STD | Input Microphone Left (Headset 0) |
| 20 | HEAD 1 (+) | Output 1 Headset-Speaker Positive |
| 21 | GND (HEAD 1) | Output 1 Headset-Speaker Negative |
| 22 | DATA-TX | RS232 TX (for Remote Control) |
| 23 | N/A | do not connect |
| 24 | +5VDC OUT | 5VDC Power Supply for Remote Control |
| 25 | BATT (-) | Ground Side of Power Supply |

3 Configuration in sky-map


3.1 Prerequisites and Configuration in iOS



iOS Settings:

1. Bluetooth must be enabled in the iOS settings.
2. Under *Apps/sky-map*, access to Bluetooth must be granted.


3.2 Prerequisites and Configuration in Android



Android Settings:

1. Bluetooth must be enabled in the Android settings.
2. Under *Apps/sky-map*, access to **Nearby devices** and **Location** must be granted.

3.3 Establishing Connection with the Adapter



3. Turn on the radio with the adapter.
4. Open in sky-map:
Menü → Setup → Wireless Interface Setup
5. Select **SD-ATR833-E** (if multiple are available).
6. Select the appropriate protocol for your radio:
Funke ATR833
7. Exit the setup.

At the next program start, sky-map will automatically reconnect to the last selected BTLE adapter.

Important: For the automatic connection at program start to work, the radio and BTLE adapter must be turned on **before** sky-map is started.

If this is not the case, the connection must be established manually by accessing the setup (see step 4).

4 Contact

For problems, questions, suggestions, or positive feedback,
please contact:

LayCom Vision GmbH – SD-Link

Michael Hoffmann

Chausseestr. 46
D-15518 Rauen, Germany

E-Mail: info@sdlk.de
Phone: +49 3361 710253

